



INSTRUCTION




PRX3000



FIXED PLATE REMOVE INSTRUCTION




ASSEMBLY DRAWING



- 1. Measure the assembling size, fix the 4-expansion screw on the wall.
- 2. Take out 24 four in one pin, fix the four in one pin to the device.
- 3.Take out 31 rear cover,52 screw M6*15,use wrench to fix the rear cover to the device.
- 4. Assemble the device, tighten the nuts.
- 5. Take out the 30 front cover, 18 screw covers and 41 screw M6*15, use wrench to fix the front cover to the device.
- 6.Take out 22 gourd hook and 29 hand bar, assemble them to the device, then finish assembling.

MAINTENANCE INSTRUCTION




The length adjustment of the cable

For the better use of this trainer, after long time use, the cable will be prolonged, there is need to adjust the cable to the best condition.

The adjustment of the cable

- 1. Take off the front cover of the trainer.
- 2.If the cable is too long,use a three in one bolt fixed multiple block selector,use the wrench 19*22 to loosen the M12 nut,then take off the pulley(note not to change the cable direction),then turn the double pulley seat clockwise by 1-2 rounds,adjust the cable to appropriate length,at last assemble the pulley,fasten the nut.As picture A.





After long time use, the cable might be worn and prolonged. When the cable is too long, can adjust double pulley seat; when the cable is seriously worn, need to change cable.

PART LIST

NO	ITEM	DESC	Q'TY	NO	ITEM	DESC	Q'TY
01	Base feet		1	02	Head piece		1
03	Left upright		1	04	Right upright		1
05	Stainless steel upright		1	06	Sliding seat		1
07	Double pulley case		2	08	Stainless steel guide bar		2
09	Connection wall board		4	10	Double pulley seat		1
11	Pulley connection long shaft	∮10*36.5	1	12	Pulley connection short shaft	∮10*27.5	9
13	Double pulley connection shaft	∮10*56.5	1	14	Small pulley shaft	∮10*29.5	1
15	Location sleeve	∮40*∮20.5*20	2	16	Rotation pulley seat shaft	∮10*72	2
17	Cable connection cover	∮22*60	2	18	Screw cover	∮19.5*2.5H	38
19	Upper weight stack	T25.4*65*230	1	20	Lower weight stack	T25.4*65*230	19
21	Weight choice	∮25*562.5	1	22	Gourd hook		2
23	Three in one pin		1	24	Four in one pin		1

NO	ITEM	DESC	Q'TY	NO	ITEM	DESC	Q'TY
25	75Pulley		12	26	50Pulley		1
27	Shaft	∮26*∮10*8	2	28	Cable connecting sleeve	∳35*50	2
29	handrail		2	30	Front cover	T6.0*380*1934	1
31	Rear cover	T4.0*260*1934	1	32	Hollow short sleeve	∮60*35	2
33	Cushion	∮50*∮20*25	2	34	Flat cushion	φ37*φ34*16*(M6* 11)	4
35	Cable	∮3.3*∮2.38*19*9 560	1	36	Square inner tube sleeve	50*100*T1.8	2
37	Stopple A	∮12*∮5*9.8	2	38	Screw	M5*10	2
39	Screw	M8*15	24	40	Screw	M6*15	2
41	Screw	M6*15	38	42	Screw	M8*15	2
43	Screw	M8*60	2	44	Screw	M10*20	2
45	Screw	M6*10	4	46	Screw	M8*10	6
47	Nut	M12*1.75	1	48	Washer	∮8.5*∮16*T1.5	28
49	Washer	∮10.5*∮20*T2.0	4	50	Nylon sleeve	∮22*13	4
51	Nylon rope	∮2.0*850	1	52	Screw	M6*15	12
53	U shape pulley protecting plate		1	54	Screw	M5*10	2





Garlando

GARLANDO SPA
Via Regione Piemonte, 32 - Zona Industriale D1
15068 - Pozzolo Formigaro (AL) - Italy
www.toorx.it - info@toorx.it